





# Pectolytic enzyme preparation for the skin maceration and elaboration of fruity and aromatic wines

## **CHARACTERISTICS**

VIAZYM MP is a micro-granulated enzyme preparation obtained from Aspergillus niger, rich in pectinases whose action is reinforced by cellulase and hemicellulase activities. Bglucosidase activities contribute to the release of aromas bound to precursors.

The absence of cinnamoyl esterase in **VIAZYM MP** prevents the formation of volatile phenols.

## **ENOLOGICAL PROPERTIES**

- The degradation of pectins improves pressing with a better juice yield and a rapid clarification of musts
- Produces compacted lees
- Degradation of plant cell walls to release the aromatic terpenic precursors
- Reveals varietal aromas (thiols)

Secondary protease activities significantly decrease the amount of bentonite needed and thus preserve the aromas extracted

#### **APPLICATION FIELD**

Skin maceration with white and rosé grape varieties for the elaboration of fruity and aromatic wines

## APPLICATION RATES

Recommended application rate: 2 to 4 g/100kg of grapes according to the grape variety, the length and temperature of maceration.

## **INSTRUCTIONS FOR USE**

Dilute **VIAZYM MP** in approximately 10 L of water or must.

Add to the volume to be treated. Ensure proper homogenization.

## Precaution for use:

Product for professional enological use only.

Use according to current regulations.

#### **PACKAGING**

100g box

#### **CONSERVATION**

Upon reception, store unopened package at a temperature below 25°C, away from frost and light in a dry and odorless area. After harvest, store at a temperature between 8°C and 15°C. Opened package: store at a temperature between 8°C and 15°C, away from frost and use rapidly.

The information provided corresponds to our current knowledge. It is given without commitment or guarantee since the conditions of use are out of our control. It does not release the user from respecting the applicable legislation and safety regulations. This document is the property of SOFRALAB and cannot be modified without authorization.

SAS SOFRALAB - 79, av. A.A. Thévenet - CS 11031 - 51530 MAGENTA - France Tél. : + 33 3 26 51 29 30 - Fax : + 33 3 26 51 87 60 - **www.martinvialatte.com**